

Clock Setting Tips – CircuPool SmartFlo Pump

1. Before setting the clock, apply power to the pump and ensure that it is in **Schedule Mode**. Then disconnect power, wait one full minute, and proceed with the steps below.
2. When power is applied to the pump, the Time LED light will begin blinking and you must press the MENU button within 5 seconds to enter the clock setup mode. **(If MENU button is not pressed within 5 seconds, begin again with step one.)**
3. Use the "<" and ">" arrows to choose between a 12 or 24 hour time format.
4. Use the "+" and "-" buttons to change the time to the correct time of day. In the 12 hour time format AM/PM will display in the bottom left corner.
5. To exit the clock setup mode, press and hold the MENU button until the TIME light goes out: The clock is now set.
6. Press START and allow pump to run on Default Schedule for at least one OFF-ON cycle.